Hood/Side Panel Coverage

Passenger's Side: Hood

Driver's Side: Hood

Center of Hood

Passenger's Side: Side Panel/Nose Cone

Driver's Side: Side Panel/Nose Cone

Mid Coverage Adds:

Passenger's Side: Tunnel Side/Gas Tank

Driver's Side: Tunnel Side/Gas Tank

Gas Tank Center

Gas Tank Rear (E-Start)


Full Coverage Adds:

Passenger's Side: Shock Tower/Knee

Driver's Side: Shock Tower/Knee

Passenger's Side: Tunnel Top


Driver's Side: Tunnel Top



Due to Ski-Doo's multiple tunnel configurations, we are unfortunately no longer able



Use this page to find each piece on your sled. The layout shows the sled from above in a flattened view. We have listed out each area by level of coverage on the top of the page to help identify where each piece goes. Each piece has a corresponding letter/number combination to help identify it between this map and the print map.











This page will help you find the general location of where each piece is located on the sled.